


ELITE NEW


AUTOMATION FOR SWING GATES

Contents

1. GENERAL SAFETY PRECAUTIONS	page	01
2. INTENDED USE AND APPLICATION	page	01
2.1 Kit contents	page	01
2.2 Technical features.....	page	02
2.3 Operator dimensions.....	page	02
3. INSTALLATION	page	02
3.1 Preliminary checks	page	02
3.2 Tools and materials (not included)	page	03
3.3 Wiring	page	04
3.4 Installing the operator	page	05
3.4.1 Quotes from ground	page	05
3.4.2 Pillar brackets	page	05
3.4.3 Outward opening	page	06
3.4.4 Pillar bracket S1	page	07
3.4.5 Gate bracket S3	page	07
4. MANUAL RELEASE	page	08
5. MAINTENANCE	page	08
6. WARRANTY	page	08
7. PHASING OUT AND DISPOSAL	page	08
8. CONFORMITY DECLARATION	page	09

1. GENERAL SAFETY PRECAUTIONS


This manual contains important information concerning personal safety. An incorrect installation or an improper use may lead to severe injuries. Read carefully and store for future use. Pay particular attention to this symbol 

 **Switch the power OFF before any operation. Double check the electrical grounding and fit a disconnection device as well as overcurrent protection.**

The installation of automatic doors and gates must comply with the Machine Directive 2006/42/CE, in particular EN 12453, EN 12635, EN 60204-1, EN 12978. The definitive connection to the power supply, as well as testing and starting shall be performed by qualified personnel, who will be held to check risks and ensure the system complies with the current regulation. This product has been designed only for its intended use. Any other use could affect the integrity and safety of the product, therefore has to be considered prohibited.

Periodically examine the automation and check for signs of wear or damage in cables and mechanical devices.

In the event that maintenance or repair is required, avoid using the automation until the installation has been fully restored.

 **Keep the remote controls away from children. Do not allow children to play within the system area.**

 **People with reduced physical, sensory, mental or limited experience and / or knowledge can use automation only if they are provided with supervision or specific instructions regarding the safe use of the same.**

Use only original spare parts. No alteration on the system has to be carried out.


Proteco Srl will not respond in case of using additional and/or fake spares.

2. INTENDED USE AND APPLICATION

The ELITE NEW operator is designed to automate swing gates. The use of this product for purposes other than those described above and installation executed in a manner other than as instructed in this technical manual are prohibited. All ELITE NEW systems are irreversible, therefore no electric-lock is needed. In case of power cut the gate operator can be easily released by manual operation.

2.1 KIT CONTENTS

Double-leaf composition




- | | | |
|----|-----|---------------------|
| 01 | n°2 | Motors |
| 02 | n°2 | Pillar brackets S1 |
| 03 | n°2 | Gate brackets S3 |
| 04 | n°2 | Fixing pack PR1-G1 |
| 05 | n°2 | Release key |
| | n°1 | Installation manual |

2.2 TECHNICAL FEATURES

		ELITE NEW 3			ELITE NEW 4 REV				ELITE NEW 5			ELITE NEW 6
Motor power supply	V	24Vdc	230V~50Hz	115V~60Hz	24Vdc	230V~50Hz	115V~60Hz	230V~50Hz	24Vdc	230V~50Hz	115V~60Hz	230V~50Hz
Max draw.	A	0,5-0,75A	1,2-1,7A	2,0-2,3A	0,5-0,75A	1,2-2A	2,0-2,3A	1,2-1,7A	0,5-0,75A	1,2-1,7A	2,0-2,3A	1,2-1,7A
Power	W	50W	280W	300W	50W	280W	300W	250W	50W	280W	300W	280W
Capacitor	µF	--	8µF	30µF	--	8µF	30µF	8µF	--	8µF	30µF	8µF
Thermal protection	°C	--	150°C	150°C	--	150°C	150°C	135°C	--	150°C	150°C	150°C
Adjustable thrust	N	2500N	2800N	3000N	2500N	2800N	3000N	2500N	2500N	2800N	3000N	2800N
Protection rating	IP	44	44	44	44	44	44	44	44	44	44	44
Revolutions	rpm	1600 rpm	1400 rpm	1700 rpm	1600 rpm	1400 rpm	1700 rpm	900 rpm	1600 rpm	1400 rpm	1700 rpm	1400 rpm
Opening angle	deg	110°deg	110°deg	110°deg	110°deg	110°deg	110°deg	110°deg	110°deg	110°deg	110°deg	120°deg
Opening time (90°)	s	15"	17"	14"	20"	22"	18"	34"	25"	27"	22"	32"
Leaf weight	Kg	275Kg	350Kg	300Kg	250Kg	350Kg	250Kg	300Kg	150Kg	250Kg	200Kg	200Kg
Leaf length	m	2,00m	2,00m	2,00m	2,50m	2,75m	2,75m	2,75m	3,00m	3,50m	3,50m	4,00m
Duty cycle	%	80%	40%	40%	80%	40%	40%	40%	80%	40%	40%	40%

2.3 OPERATOR DIMENSIONS



3. INSTALLATION

3.1 Preliminary checks

Before installing make sure:

- Weight, dimensions and gate construction are proper for the operator you intend to buy
- Proper mechanical stops are already in place
- The gate swings freely
- The opening of the automated gate is not an entrapment hazard as regards any surrounding fixed parts and there is sufficient space for manual release
- Any lawn watering devices will not wet the gearmotor from the bottom up
- The earth cable is properly connected
- Do not install onto gates on either an upward or downward slope (i.e. that are not on flat, level ground)

3.2 TOOLS AND MATERIALS (NOT INCLUDED)

PILLARS AND WALLS



brick



concrete



inox/alu. tubular



stainless steel



3+3
Ø 18mm



3+3
Ø 15mm



3+3




3+3


LEAF



stainless steel/alu













wood




2+2



2+2



3.3 WIRING INSTALLATION OVERVIEW



N.B.: The number of tubes and cables (not included in the kit) depends on the type of the accessories employed

CABLES NEEDED

230V	
A Ram	3 x 1,5 mm ² + Terra
B Control panel	2 x 1,5 mm ² + Terra
C Photocells	rx 4 x 0,50 mm ²
C' Photocells	tx 2 x 0,50 mm ²
D Key switch	2 x 0,50 mm ²
E Flashing light	2 x 0,50 mm ²

24V	
A Ram	2 x 1,5 mm ²
B Control panel	2 x 1,5 mm ² + Terra
C Photocells	rx 4 x 0,50 mm ²
C' Photocells	tx 2 x 0,50 mm ²
D Key switch	2 x 0,50 mm ²
E Flashing light	2 x 0,50 mm ²

- Cut off the power before starting wiring
- A circuit breaker should be fitted close to the gate (3 mm wires) to protect both the gate control panel and the house main fuse box. A 6A automatic breaker or a 16A single phase breaker complete with fuses shall be suitable.
- Make sure you have suitable tubing and conduits for the electrical cables: feed the motors, control panel and accessories separately, in order to prevent interferences that may result in bad operation.
- Fit the power cable keeping a curve as shown in picture B, in order to avoid water blackflow inside the operator. (pic. B)





fig. B

3.4 INSTALLING THE OPERATOR


The kit is supplied with a right and a left hand motor and are specific. Ensure you are mounting the correct handed motor to the leaf. See picture C. Make sure there is a mechanical stop (**B**) for opening and closing.



B = mechanical ground stops


3.4.1. QUOTES FROM GROUND

The operator has to be fitted keeping a height from ground between **40 and 50 cm**. See picture D. If the gate is particularly light, fit the operator as closer as possible to gate centerline.




3.4.2. PILLAR BRACKETS – How to determine fixing dimensions

The ideal approach is to fix the brackets complying with the measures A and B as indicated in the below table for an opening angle of 90° (picture E).



Elite New 3 A=150 B=150
 Elite New 4 A=200 B=200
 Elite New 5 A=250 B=250
 Elite New 6 A=300 B=300



If this ideal scenario of A and B is not applicable, then refer to the below table to determine the brackets position
(values are expressed in mm)

Elite New 6	D	275	250	225	200	175	150	125	100	75
	A	275	300	295	290	315	310	335	360	385
	B	325	300	305	310	285	290	265	240	215
	Bracket quota	50	50	80	110	110	140	140	140	140
	Minimum Leaf length	1300	1240	1280	1280	1260	1270	1240	1220	1200


Elite New 5	D	225	200	175	150	125	100	75	50	25
	A	225	250	245	240	235	260	285	310	335
	B	275	250	255	260	265	240	215	190	165
	Bracket quota	50	50	80	110	140	140	140	140	140
	Minimum Leaf length	1150	1130	1130	1130	1140	1120	1100	1070	1050

Elite New 4	D	200	175	150	125	100	75	50	25	0
	A	140	170	200	195	190	185	210	235	260
	B	250	225	200	205	210	215	190	165	140
	Bracket quota	50	50	50	80	110	140	140	140	140
	Minimum Leaf length	1030	1000	980	990	990	970	970	950	930

Elite New 3	D	150	125	100	75	50	25	0
	A	100	125	150	145	140	135	160
	B	200	175	150	155	160	165	140
	Bracket quota	50	50	50	80	110	140	140
	Minimum Leaf length	880	860	840	840	850	850	830


3.4.3. OUTWARD OPENING

It's possible to have your gate opening outward (fig. F-G)





3.4.3. PILLAR BRACKET S1

Anchor the pivot bracket S1 onto the pillar by welding or bolting (\varnothing 13 mm bolts), making sure the quotas shown in the previous table are met. Ensure to keep a minimum distance of 30 mm from the pillar edge as shown in picture H.





In cases of masonry pillars, use chemical or resin to secure bolts or stone (cement) the bracket into position. Brackets S1 as well are supplied in two versions, left hand and right hand and match the according motor (see picture I). Fix motor into bracket S1 and place the pivot pin PR1 through the holes. Keep the pivot pin PR1 oriented downward. See picture L.



3.4.4. GATE BRACKET S3

To determine the position of bracket S3:

- Put the gate in closing position
- Release the operator (see paragraph 4)
- Extend the arm fully
- Turn back the arm 2 cms. This avoids the motor to “leap forward”(pic. M)
- Affix the bracket S3 to the motor slot as illustrated in picture M. Place the pivot pin PR1 into the locating hole.
- Mount the arm of the motor onto the gate. Ensure the arm is perfectly straight.



NB.


Check the manual opening of the leaf before definitively fixing the bracket to make sure the gate can open fully to your required angle.

4. MANUAL RELEASE

Insert the hexagonal release key (included in the fixing pack) and turn 90°. See pictures O/P.

Now proceed to manual opening. To lock back the operator, insert the key and turn 90°.

The gate can be locked in any position since after the first start command the system will return to its default settings



5. MAINTENANCE

Periodic maintenance is needed. We suggest checking the state of lubrication and tightness of the anchoring screws on the operator as well as the good operation of all safety devices.

6. WARRANTY

All goods supplied by PROTECO are covered by a limited warranty of 3 years from the production date printed on the product.

In this period, Proteco Srl offers a free guarantee against malfunction due to defects in workmanship and materials.

Any form of guarantee provided here is strictly conditional upon compliance with the instructions for use and maintenance.

The limited warranty does not apply when the goods are not PROTECO'S originals and the fault comes from an incorrect installation or is due to force majeure.

The installation and any maintenance works are the responsibility of who installs the system.

Under no circumstances and in no way Proteco Srl will be liable for damages, including any

loss of profits, savings, or other incidental or consequential damages, resulting from the use or inability to use the PROTECO products.

Any return coming without previous authorization will be rejected.

Returning shipping costs will be at customer's charge.

All faulty items have to be returned along with the according invoice to:

PROTECO Srl Via Neive 77, 12050 Castagnito (CN) - Italia

The limited warranty is not applicable when:

- Goods have been handled or stored in abnormal use and maintenance conditions
- Goods have been repaired, changed and altered by unauthorized personnel
- Goods have been subject to incorrect use, neglect, electrical problems, improper packaging, accidents or natural events
- Goods have been installed in an improper way.
- The label of the product warranty is illegible or missing.
- Bad operation is due to incorrect installation, natural or accidental events (falls, surcharges, oxidation)

7. PHASING OUT AND DISPOSAL



DO NOT DISPOSE OF IN NATURE!

Some components may contain hazardous waste. They must, thus, be removed and turned in to licensed firms for their disposal. Before acting always check the local laws on the matter.

8. DECLARATION OF CONFORMITY

Translation of the original declaration

In accordance with Annex II B of Machinery Directive 2006/42/CE

The legal representatives of



Proteco S.r.l. via Neive 77 12050 Castagnito (CN) Italia
tel (+39) 0173210111 fax (+39) 0173210199
www.proteco.net info@proteco.net

hereby declare that the products listed below

**Elite New 3, Elite New 4, Elite New 5,
Elite New 3 24, Elite New 4 24, Elite New 5 24,
Elite New 3 115, Elite New 4 115, Elite New 5 115**

electromechanical gear motor for swing gates

comply the following Essential Requirements of Directive 2006/42/CE Annex I
(Machinery directive):

1.1.2 1.1.3 1.1.5 1.2.1 1.2.2 1.2.3 1.2.6 1.3.2 1.3.4 1.3.9 1.4.1
1.4.2.1 1.5.1 1.5.4 1.5.6 1.5.8 1.5.13 1.6.1 1.6.4 1.7.1 1.7.3 1.7.4

are in conformity with the following directives:

2014/35/UE (LVD)

2014/30/UE (EMC)

2014/53/UE (RED)

The above listed products are delivered, limitedly to the applicable parts, according to the following standards:

**EN 61000-6-2
EN 61000-6-4
EN 61000-3-2
EN 61000-3-3
EN 12453
EN 60335-1
EN 60335-2-103**

They also state that:

- the relevant technical documentation is compiled in accordance with part B of Annex VII of directive 2006/42/CE
- the relevant technical documentation is compiled and preserved by PROTECO SRL which undertakes to transmit it by mail in response to a reasoned request by the national authorities.
- the partly completed machinery must not be put into service until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of the directive 2006/42/CE

Castagnito, 29.01.2018

A handwritten signature in black ink, appearing to read "Felloni".

