



**100 CM**

# GARDENSPIN

LANDING BANISTER | GARDE-CORPS ÉTAGE | BORSTWERINGEN OP VERDIEP | BRÜSTUNGSGELÄNDER  
BALAUSTRADA | GUARDACORPO | RINGHIERA PER BALCONE | GARDĂ DE CORP ETAJ

<p>1</p> <p>902mm</p>	<p>2</p> <p>980mm</p> <p>1000mm</p> <p>(I) : x 1 (II) : x 1</p>	<p>3</p> <p>(I) : x 2 (II) : x 2</p>	<p>4</p> <p>(I) : x 2 (II) : x 0</p>			
<p>14</p> <p>(I) : x 1 (II) : x 0</p>	<p>7</p> <p>Ø 42mm</p> <p>(I) : x 1 (II) : x 1</p>	<p>5</p> <p>(I) : x 9 (II) : x 9</p>	<p>6</p> <p>(I) : x 1 (II) : x 0</p>			
<p>20</p> <p>(I) : x 6 (II) : x 4 Ø8x60</p>	<p>8</p> <p>(I) : x 2 (II) : x 0</p>	<p>9</p> <p>Ø 34mm</p> <p>150mm</p> <p>(I) : x 0 (II) : x 1</p>	<p>10</p> <p>(I) : x 0 (II) : x 1</p>	<p>11</p> <p>(I) : x 2 (II) : x 0</p>	<p>12</p> <p>Ø 20mm</p> <p>150mm</p> <p>(I) : x 1 (II) : x 0</p>	<p>26</p> <p>(I) : x 1 (II) : x 1</p>
<p>21</p> <p>(I) : x 6 (II) : x 4 Ø8</p>	<p>22</p> <p>Ø10x60</p> <p>(I) : x 6 (II) : x 4</p>	<p>23</p> <p>(I) : x 15 (II) : x 13 M8x8</p>	<p>24</p> <p>(I) : x 9 (II) : x 9 M5x14</p>	<p>25</p> <p>(I) : x 9 (II) : x 9 M5</p>	<p>26</p> <p>(I) : x 1 (II) : x 1</p>	

	62141580	62141585
	I	II
FR	KIT DE DÉPART	KIT DE SUITE
NL	VERTREK KIT	UITBREIDINGSSET
GB	START KIT	EXTENSION KIT
DE	ABFAHRTSATZ	ERWEITERUNGSSATZ
ES	KIT DE SALIDA	KIT DE EXTENSION
RO	KIT DE PLECARE	KIT EXTENSIE









