


ASSEMBLY INSTRUCTION

DE - MONTAGEANWEISUNG
FR - INSTRUCTIONS DE MONTAGE
DK - MONTAGEVEJLEDNING
CZ - NÁVOD K MONTÁŽI
ES - INSTRUCCIONES DE MONTAJE
FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU
SE - MONTERINGSANVISNING
SI - NAVODILA ZA MONTAŽO
TR - MONTAJ TALIMATI
NO - MONTASJEANVISNING
IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ
NL - MONTAGE INSTRUCTIE
PT - INSTRUÇÕES DE MONTAGEM
PL - INSTRUKCJA MONTAŻU
HU - SZERELÉSI UTASÍTÁS



20 min



IMPORTANT - A LIRE ATTENTIVEMENT ET A CONSERVER POUR UTILISATION ULTERIEURE

0 cm
1
2
3
4
5
6
7
8
9
10
11
12
13
14



x 3

HW-ST-02-143
(8 x 30)

2



x 3

HW-ST-07-062
(8.5x12.5x1.5)


3



x 3

HW-ST-07-054
(8.5x20x2)


4



x 3

HW-ST-03-019
(6 x 20)


5



x 1


HW-ST-18-007
(13 x 88)

6




x 1


HW-ST-18-001
(4x98)



A x 1
SU-TB-TF-1807



B x 3
SU-TB-LF-1284



7 x 1
HW-ST-23-032
(555x441x14(t Ø6))

