

## Kettleman - model 16309001

Key	Qty	Description	Part #	Kriswell Art.No.
1	1	LID W/ DAMPER	HW018-110100	150 900
2	1	LOGO PLATE	HW018-110200	150 901
3	1	LID HANDLE	HW018-110400	150 902
4	1	TEMPERATURE GAUGE W/ BEZEL	HW018-111100	150 903
5	1	FIREBOWL	HW018-020100	150 904
6	1	LATCH	HW018-120400	150 905
7	1	WIND GUARD	HW018-030000	150 906
8	1	ASH CATCHER SUPPORTS	HW018-070001	150 907
9	1	ASH CATCHER PAN	HW018-130000	150 908
10	1	CHARCOAL GRID	HW018-140000	150 909
11	1	COOKING GRATE	HW018-150000	150 910
12	1	COOKING GRATE HANDLE (SET of 2)	HW018-160001	150 911
13	1	LEG, FRONT	HW018-170101	150 912
14	1	LEG, REAR LEFT	HW018-170200	150 913
15	1	LEG, REAR RIGHT	HW018-170300	150 914
16	1	LEG CAP	HW018-170104	150 915
17	1	BOTTOM SHELF	HW018-170401	150 916
18	2	WHEEL	HW018-170500	150 917
19	1	DAMPER	HW018-110700	150 918
...	1	HARDWARE PACK	HW018-230000	150 919
...	1	ASSEMBLY MANUAL, EUROPEAN	29104670	150 920

## PARTS LIST

Key	Qty	Description
1	1	LID WITH DAMPER
2	1	LOGO PLATE
3	1	LID HANDLE
4	1	TEMPERATURE GAUGE W/ BEZEL
5	1	FIREBOWL
6	1	LATCH
7	1	WIND GUARD
8	1	ASH CATCHER SUPPORTS
9	1	ASH CATCHER PAN
10	1	CHARCOAL GRID
11	1	COOKING GRATE

Key	Qty	Description
12	1	COOKING GRATE HANDLE (SET of 2)
13	1	LEG, FRONT
14	1	LEG, REAR LEFT
15	1	LEG, REAR RIGHT
16	1	LEG CAP
17	1	BOTTOM SHELF
18	2	WHEEL
19	1	DAMPER

### NOT Pictured

...	1	HARDWARE PACK
...	1	PRODUCT GUIDE

# PARTS DIAGRAM

