

orologio da parete *Wall Clock*



FACILE DA APPENDERE!


batteria/e AA non inclusa/e.



EASY TO HANG UP!

Insert AA battery.

Battery not included



ATTENZIONE

Impostare l'orario solamente ruotando la rotella posta sul retro.

WARNING:

Set the time only by turning the wheel on the back.



IT Il simbolo del cassonetto barrato indica che il prodotto elettronico NON deve essere considerato come un normale rifiuto domestico. Deve essere consegnato ad un centro autorizzato di raccolta per il riciclo di prodotti elettrici ed elettronici. In questo modo è possibile preservare le risorse naturali e migliorare la protezione dell'ambiente in cui viviamo.

UK The symbol of crossed out bin means that the electronic product should NOT be considered as normal household waste. It must be delivered to a center authorized to recycle electrical and electronic products. In this way it is possible to preserve natural resources and improve the protection of the environment we live in.

SCATOLA



CARTA

INVOLUCRO
ESTERNO



PLASTICA

**RACCOLTA
DIFFERENZIATA**
segui le regole
del tuo Comune

MAZZOLENI
HOME AND CREATIVITY

Imported by: Mazzoleni T. & C. Srl
via Natta, 2 - 24030 Mapello (Bg) Italy
www.mazzoleni.eu