







| | | | |
|---|---------------------|---|---|
| 1 | General information | Supplier's name or trade mark | No name |
| 2 | | Supplier's address | ADEO Services, 135 rue Sadi Carnot - CS00001, 59790 RONCHIN |
| 3 | | Model Identifier - Luminaire Supplier reference | FC-N1-MN-600-PIR |
| 4 | | Light sources maker model | FC-N1-MN-600-PIR |

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

| | Explanation of the step | Pictures | Tools |
|---------------|--|--|--------------------------------|
| Step 1 | Turn the lampshade counterclockwise |  | By hand |
| Step 2 | Rotate counterclockwise with a Phillips screwdriver (φ5) and remove 4pcs screws for the shielding and 2pcs screws for the drive box respectively |  | By a Phillips screwdriver (φ5) |
| Step 3 | Use a flat-head screwdriver (φ3) to pry open the buckle of the shielding and the light source for four times, and take out the light source |  | Flat-head screwdriver(φ3) |
| Step 4 | Drive the output line under the light source plate with soldering iron |  | soldering iron |
| Step 5 | Weld the light wire for test |  | soldering iron |
| Step 6 | Light source assembly display |  | By hand |
| Step 7 | | | |