$\Lambda$		LIGHT SOURCE REMOVING INSTRUCTION	Creation date (dd/mm/yyyy):	2021/9/7	
QUALITY			Last update date (dd/mm/yyyy):	2021/9/7	
1	rtion	Supplier's name or trade mark	INSPIRE		
2	forma	Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RON	CHIN	
3	eral in	Model Identifier - Luminaire Supplier reference	5105003125		
4	Gene	Light sources maker model	5105003125M		

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explaination of the step	Pictures	Tools
Step 1	Unscrew the external screws and remove the base		Screwdrvier - Crosshead
Step 2	Unscrew the fixing screws and remove the diffuser		Screwdrvier - Crosshead
Step 3	Unscrew the screw on the terminal		slotted screwdriver
Step 4	LED module		
Step 5			
Step 6			
Step 7			
Step 8			
Step 9			
Step 10			