

LIGHT SOURCE REMOVING INSTRUCTION		Creation date (dd/mm/yyyy) :	10/10/2022
		Last update date (dd/mm/yyyy) :	10/10/2022
1	General information	Supplier's name or trade mark	ADEO Services,
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN
3		Model Identifier - Luminaire Supplier reference	GE00201-2
4		Light sources maker model	QY200696-14-2835

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explanation of the step	Pictures	Tools
Step 1	Open the stainless steel panel	 	hexagon wrench
Step 2	Unscrew the screws that fix the LED board and the control board	 	screwdriver
Step 3	Unscrew the LN wire on the control board, and take out the control board and LED board, the removal procedure is complete	 	screwdriver
Step 4			
Step 5			
Step 6			by hand