

LIGHT SOURCE REMOVING INSTRUCTION

Creation date (dd/mm/yyyy) :


17/10/2022

Last update date (dd/mm/yyyy) :

17/10/2022

1	General information	Supplier's name or trade mark	INSPIRE
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN
3		Model Identifier - Luminaire Supplier reference	F2101D
4		Light sources maker model	F2101

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explanation of the step	Pictures	Tools
Step 1	The whole product		
Step 2	Remove the housing		
Step 3	Pry the bottom shell with tweezers		Tweezers
Step 4	Take out reflective paper and light guide plate		
Step 5	Take out the light board		
Step 6	Weld the light plate with a soldering iron		Soldering iron
Step 7	The light source.		
Step 8			
Step 9			
Step 10			