

## LIGHT SOURCE REMOVING INSTRUCTION

Creation date (dd/mm/yyyy) :


17/10/2022

Last update date (dd/mm/yyyy) :

17/10/2022

1	General information	Supplier's name or trade mark	INSPIRE
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN
3		Model Identifier - Luminaire Supplier reference	<i>6007DOB-60-WH</i>
4		Light sources maker model	<i>6007DOB-60</i>

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explanation of the step	Pictures	Tools
<b>Step 1</b>	The whole product		
<b>Step 2</b>	Take out the plug on the light.		Phillips screwdriver
<b>Step 3</b>	Remove the end cover on both side.		Phillips screwdriver
<b>Step 4</b>	Take out the bottom cover of the light.		
<b>Step 5</b>	Remove the terminal block and junction box		
<b>Step 6</b>	Take out the controller.		
<b>Step 7</b>	Control box		
<b>Step 8</b>	Remove the up and bottom cover of the control box		
<b>Step 9</b>	Control panel		
<b>Step 10</b>	Take out the PC cover.		

<b>Step 11</b>	Take out the light board and the wiring board		
<b>Step 12</b>	The light source.	