

LIGHT SOURCE REMOVING INSTRUCTION

Creation date (dd/mm/yyyy) :



17/10/2022

Last update date (dd/mm/yyyy) :

17/10/2022

1	General information	Supplier's name or trade mark	INSPIRE
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN
3		Model Identifier - Luminaire Supplier reference	N2128016-5-40K
4		Light sources maker model	N212816

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explanation of the step	Pictures	Tools
Step 1	The whole product		
Step 2	Cut the 70 cm sleeve at the end of the lamp with a knife		knife
Step 3	Pull out the cut sleeve		
Step 4	Cut the 0.5m module with scissors		scissors
Step 5	The light source.		
Step 6	Driver		
Step 7			
Step 8			
Step 9			
Step 10			