

LIGHT SOURCE REMOVING INSTRUCTION

Creation date (dd/mm/yyyy) :

01/11/2022

Last update date (dd/mm/yyyy) :

01/11/2022

1	General information	Supplier's name or trade mark	INSPIRE
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN
3		Model Identifier - Luminaire Supplier reference	5934-BK; 5934-WH
4		Light sources maker model	5934

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explanation of the step	Pictures	Tools
Step 1	The whole product		
Step 2	Unscrew the screws with a cross screwdriver		Cross screwdriver
Step 3	Remove the end cap		
Step 4	Remove the PC cover		
Step 5	Remove the light guide board		
Step 6	Remove reflective paper		
Step 7	Remove plastic parts with tweezers		tweezers
Step 8	Remove the PCB wire with an electric soldering iron		electric soldering iron
Step 9	The light source		
Step 10			