

The tado° logo is positioned in the top left corner of the image. It features the brand name in a dark, sans-serif font, with a small degree symbol (°) as a superscript to the letter 'o'.

tado°

A vertical stack of six language selection buttons is located in the top right corner. Each button is a small, rounded rectangle with a dark background and white text. The languages listed from top to bottom are: EN, DE, NL, IT, ES, and FR.

EN
DE
NL
IT
ES
FR

A white, rounded rectangular text box is located in the lower-left area of the image. It contains the word 'Hello!' in a large, bold, black sans-serif font.

Hello!

A white, rounded rectangular text box is located in the lower-left area of the image, below the 'Hello!' box. It contains the text 'Meet your tado° Smart AC Control' in a black sans-serif font.

Meet your tado° Smart AC Control

STEP 1



Download the mobile app

Lade die App herunter

Download de app

Scarica l'app

Descarga la aplicación para móvil

Téléchargez l'application



STEP 2

Create an account and install devices using the mobile app

Konto erstellen und Geräte über die mobile App installieren

Maak een account aan en installeer de apparaten via de app

Crea un account e installa i dispositivi utilizzando l'app

Crea una cuenta e instala los dispositivos usando la aplicación móvil

Créez un compte et installez les appareils à l'aide de l'application



CHANGE SETTINGS VIA DEVICE



Touch to activate display

Berühren um Display zu aktivieren
Raak aan om het display te activeren
Tocca per attivare il display
Toca para activar la pantalla
Touchez pour activer l'affichage

Touch to change settings

Berühren um Einstellungen zu ändern
Raak aan om de instellingen te veranderen
Tocca per modificare le impostazioni
Toca para cambiar los ajustes
Touchez pour modifier les paramètres



Home



Away



Manual

Press and hold to quickly turn AC on or off

Gedrückt halten, um die Klimaanlage ein- oder auszuschalten

Ingedrukt houden om de airco in en uit te schakelen

Tieni premuto per avviare o spegnere il climatizzatore

Mantén pulsado para apagar o encender el AC rápidamente

Appuyez et maintenez pour allumer ou éteindre le climatiseur rapidement





Problems or questions? [**tado.com/support**](https://tado.com/support)

Probleme oder Fragen? [**tado.com/support**](https://tado.com/support)

Problemen of vragen? [**tado.com/helpdesk**](https://tado.com/helpdesk)

Problemi o domande? [**tado.com/aiuto**](https://tado.com/aiuto)

¿Problemas o preguntas? [**tado.com/asistencia**](https://tado.com/asistencia)

Des problèmes ou des questions ? [**tado.com/assistance**](https://tado.com/assistance)

