




Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικός Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zarasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli / Pjese kembimi


XX = AA, AD, .....

- 1 - B 961565 XX
- 3 - B 964696 NU
- 4 - B 961229 XX
- 5 - B 961230 NU
- 7 - B 961477 NU
- 7a - B 961479 NU
- 9 - A 960537 XX
- 10 - B 960486 XX
- 11 - B 960167 XX
- 12 - A 960944 NU
- 15 - A 963489 XX
- 20 - B 960645 NU
- 21 - B 960646 XX
- 22 - B 961346 NU



OGGIO

10.2018 / B665854



B C318 ..

B C319 ..



Ideal Standard International NV  
Corporate Village – Gent Building  
Da Vincilaan 2  
1935 Zaventem  
Belgium  
<http://www.idealstandardinternational.com>

