




LIGHT SOURCE REMOVING INSTRUCTION		Creation date (dd/mm/yyyy) :	2023/8/10
		Last update date (dd/mm/yyyy) :	2023/8/10
1	General information	Supplier's name or trade mark	NO NAME
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN
3		Model Identifier - Luminaire Supplier reference	2128k-DB-WP
4		Light sources maker model	2128K-5M-WP

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explanation of the step	Pictures	Tools
Step 1	The whole product		
Step 2	Cut from the terminal of the light strip		Scissors
Step 3	Cut the 0.5m module with scissors and pull out the PCB board		
Step 4	The light source		
Step 5	Driver		
Step 6			
Step 7			
Step 8			
Step 9			
Step 10			