



1. Thermometer	31. Bottom Panel	61.
2. Thermometer Bezel	32. Front Frame	62.
3. Logo Plate	33. Locking Caster	63.
4. Lid	34. Left Door	64.
5. Lid Handle Bezel	35. Right Door	65.
6. Lid Handle	36. Door Handle Bezel	66.
7. Warming Rack	37. Door Handle	67.
8. Cooking Grate	38. Lid Hardware	68.
9. Flavorizer Bar	39. Inner Cooking Grate	69.
10. CROSSOVER Burner Tube	40. Right Side Table	70.
11. Burner Tube	41. iGrill 3 Ready Plate	71.
12. Igniter Electrode	42. Rear Frame Trim	72.
13. Heat Deflector	43. Rear Frame	
14. Warming Rack Bracket	44. Rear Panel	
15. Burner Tube Bracket	45. Right Side Panel	
16. Side Table	46. Cylinder Holder	
17. Cookbox	47. Rear Tank Shield	
18. Manifold Wire Clip	48. Front Tank Shield	
19. Manifold	49. Igniter Module	
20. Grease Tray Rail	50. Ground Wire	
21. Slide Out Grease Tray	51. Manifold Hose	
22. Left Side Panel	52. Bulkhead	
23. Control Panel Trim	53. Hose / Regulator	
24. Control Panel	54. Wheel Hub Cap	
25. Igniter Button	55. Wheel	
26. Igniter Button Wire	56. Axle	
27. Control Knob	57. Matchstick Holder	
28. Disposable Drip Pan	58.	
29. Catch Pan	59.	
30. Mid-Shelf	60.	