

TZ00349073

Imou

Quick Start Guide

V1.0.0

× 1

× 1

× 1

× 1

× 4

× 4

LED 1

Microphone

Speaker

LED 2

RESET

Power

QR

Lock

USB

Shopping cart

Phone

Camera

service.global@imoulife.com

<https://www.imoulife.com/support/faq>

<https://www.imoulife.com>

@imouglobal

Headset

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

1

Power On the Camera

2

Get the Imou Life App

3

Set Up the Camera

4

Install the Camera

i If you need to reset the camera, press and hold the reset button for 5 s. Double press the reset button to enter the AP mode.

i Um die Kamera zurückzusetzen, halten Sie die Rücksetztaste 5 Sekunden lang gedrückt. Drücken Sie zum Aufrufen des AP-Modus zweimal die Rücksetztaste.

i Si vous avez besoin de réinitialiser la caméra, maintenez le bouton de réinitialisation enfoncé pendant 5 s. Appuyez deux fois sur le bouton de réinitialisation pour passer en mode point d'accès.

i Houd de resetknop 5 seconden ingedrukt om de camera te resetten. Druk tweemaal op de resetknop om naar de AP-modus te gaan.

i Si tiene que reiniciar la cámara, mantenga pulsado el botón de reinicio durante 5 segundos. Pulse dos veces el botón de reinicio para entrar en el modo AP.

i Se for necessário reiniciar a câmara, prima sem soltar o botão de reiniciar durante 5 seg. Prima duas vezes o botão de reiniciar para entrar no modo AP.