LIGHT SOURCE REMOVING INSTRUCTION			Creation date (dd/mm/yyyy) :	16/04/2021
			Last update date $(\mathrm{dd}/\mathrm{mm}/\mathrm{yyyy})$:	16/04/2021
1	neral informati	Supplier's name or trade mark	VOLGA	
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN	
3		Model Identifier - Luminaire Supplier reference		
4		Light sources maker model	FL7212Y-PCB	

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explaination of the step	Pictures	Tools
Step 1	unlock clips by screw driver		screw driver
Step 2	OPEN the lamp cover		NA
Step 3			
Step 4			
Step 5			
Step 6			
Step 7			
Step 8			

Step 9		
Step 10		