




- 1: Thermometer
- 2: Bezel
- 3: Logo Plate
- 4: Lid
- 5: Warming Rack
- 6: Cooking Grate
- 7: FLAVORIZER BAR
- 8: CROSSOVER Burner Tube
- 9: Burner Tube
- 10: Igniter Electrode
- 11: Cookbox
- 12: Manifold
- 13: Igniter Button
- 14: Igniter Wire
- 15: Control Panel
- 16: Control Knob
- 17: Fold-Down Table
- 18: Fold-Down Table Bracket
- 19: Left Cookbox Frame
- 20: Front Cross Brace
- 21: Left Frame
- 22: Left Frame Pad
- 23: Front Frame Brace
- 24: Igniter Module
- 25: Right Wheel Frame
- 26: Rear Wheel Bracket
- 27: Front Wheel Bracket
- 28: Lid Hardware
- 29: Inner Cook Grate
- 30: Heat Deflector
- 31: Grease Tray Rail
- 32: Disposable Grease Tray
- 33: Manifold Hose
- 34: Slide-Out Grease Tray
- 35: Rear Cross Brace
- 36: Right Cookbox Frame
- 37: Right Side Table
- 38: iGrill 3 Ready Plate
- 39: Rear Frame Brace
- 40: Slat
- 41: Cylinder Holder
- 42: Bulkhead
- 43: Hose & Regulator
- 44: Wheel Hub Cap
- 45: Wheel
- 46: Axle
- 47: Matchstick Holder