



Gartenschere B/S-XL
Gartenschere PremiumCut Pro Flex

Art.-Nr. 8905
Art.-Nr. 12252




Bild Nr. Picture No	Ersatzteil-Nr. Spare Part No.	Bezeichnung	Description	Désignation
Art. 12252		Gartenschere PremiumCut Pro Flex	Secateurs PremiumCut Pro Flex	Sécateur PremiumCut Pro Flex
1	8905-00.600.51	Schieber	Slide	Verrou
2	8905-00.600.26	Arretierung	Locking device	Bouton d'arrêt
3	6500-00.610.00	Pin, kpl.	Pin, cpl.	Pin, cpl.
6	8905-00.600.31	Gewerbeschraube	Screw	Vis
7	8905-00.600.02	Messer unten	Bottom blade	Lame inférieure
8	8905-00.600.36	Gewerbemutter	Nut	Ecrou
9	8905-00.600.56	Blattfeder	Flat spring	Ressort à lames
10	8905-00.600.42	Puffer	Buffer	Butée
12	12251-00.600.01	Messer oben	Top blade	Lame supérieure
13	8905-00.600.46	Zeiger	Indicator	Pointeur
14	945-00.000.11	O-Ring 4,9x1,9	O-ring 4,9x1,9	Joint torique 4,9x1,9
15	8788-00.600.11	Exzenter	Eccentric	Excentrique

**Nur die aufgeführten Teile
sind lieferbar!**

**Only the mentioned
spare parts are available!**

**Seules les pièces indiquées
sont disponibles!**