



# Spare Parts list

Part No	Supplier Reference	Description	QTY
1	3030017.003	Bolt	1
2	3990001.029	Magnet	1
3	3010009.006	Washer	1
4	3060010.001	Gear	1
5	3030012.013	Pin	2
6	3040001.005	Activity blade	1
7	3020012.014	Sheath	1
8	3040030.002	Fixed blade	1
9	3010006.002	Nut	1
10	3010005.01	Screw	6
11	3060010.002	Gear	1
12	3010001.043	Screw	2
13	3010012.015	Bearing	1
14	3030004.014	Shaft	1
15	3010001.041	Screw	1
16	3020003.001	Gear box	1
17	3060007.002	Ring gear	1
18	3060006.004	Planet carrier	1
19	3060006.005	Planet carrier	1
20	3020070.003	Planet gear	6
21	3060006.003	Planet carrier	1
22	3060005.003	Planet gear	3
23	3040013.005	Spacer	1
24	3020124.003	Position plate	1
25	3010002.019	Screw	2
26	3060001.012	Motor pinion	1
27	3010001.036	Screw	1
28	3050101.031	Motor	1
29	3050605.008	Motor Control and Circuit Board Assembly	1

# Spare Parts list

Part No	Supplier Reference	Description	QTY
30	2800001.001	Plug	1
31	3040021.001	Clasp	1
32	2058015.001	Battery pack	1
33	3010001.035	Screw	3
34	3020127.001	Right pinch plate	1
35	3020001.062	Right shell	1
36	3010019.001	Steel ball	1
37	3020020.005	Button	1
38	3010001.016	Screw	1
39	3020072.003	Light pole	1
40	3020001.056	Left shell	1
41	3020127.001	Left pinch plate	1
42	3020009.016	Main switch trigger	1
43	3030089.003	Spring	1
44	3020052.021	Lock-off button	1
45	3030026.001	Spring	1
46	3010001.017	Screw	1
47	3040017.003	Contact chip	1
48	3030083.003	Torsional spring	1
49	3020082.024	Pin	1
50	3030012.016	Button	1
51	3990001.033	USB cable	1