



Caution:
When the product is used outdoors
the mains plug must be connected to
socket outlet located indoors

WiZ




WiZ Fairy Light Manual
9290041012, 9290041013
9290041016

Incl.

A



B





160 LEDs


9290041012 9290041013 9290041016




B



①




!




②



③



④



⑤

