




CAB 102A

Terry

J-Lock



IT Istruzioni per il Montaggio,
l'Uso e la Manutenzione

ES Instrucciones de Montaje,
Utilización y Mantenimiento

PT Instruções de Montagem,
Utilização e Manutenção

FR Notice de Montage -
Utilisation - Entretien


EN Assembly - Use -
Maintenance Manual

PL Instrukcja Montażu,
Użytkowania i Konserwacji




RO Instrucțiuni de asamblare
- Utilizare - Întreținere

EL Εγχειρίδιο συναρμολόγησης,
χρήσης και συντήρησης


www.terry.it



PZ2




A x2




DXP x1



SXP x1




Fsx x3




Fdx x3


B02 x3



B01 x3




T x2



U x1



M x2



SXA x1



DXA x1




PM x1




P x4



V x1



BP x18




PM x2




L x2




R x1




Y2 x1




Y1 x1



Y x1




Y4 x1



O x5




N x18



X x4




Z x1



Sts x2



VS x12 + x12 + x12



VP x4



RS x4



SX-L x1



DX-R x1



Gdx x1

