LIGHT SOURCE REMOVING INSTRUCTION

Creation date (dd/mm/yyyy) :	24/09/2021
Last update date (dd/mm/yyyy) :	24/09/2021

1	General information	Supplier's name or trade mark	INSPIRE
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN
3		Model Identifier - Luminaire Supplier reference	PL942
4		Light sources maker model	08PL942D-00-01E

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explaination of the step	Pictures	Tool
Step 1	Pull out the end cover rubber plug of the round cover	 	
Step 2	Unscrew the screw with a screwdriver	 	
Step 3	Remove the round cap	 	
Step 4	Pull out the round aluminum tube	 	
Step 5	Remove the battery and control panel	 	
Step 6	Unscrew the two internal screws	 	
Step 7	Pull out connection handle and internal light panel	 	

Step 8	Reinstall the new light board	 	
Step 9	Install the connecting handle and turn the screws	 	
Step 10	Install the battery and control panel, and plug in the terminals.	 	
Step 11	Install back round aluminum tube	 	
Step12	Reinstall the round cap and screw in	  	
Step 13	Retracting end cover rubber plug, replacement light source lamp board completed	 	