


1	General information	Supplier's name or trade mark	INSPIRE
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS00001, 59790 RONCHIN
3		Model Identifier - Luminaire Supplier reference	FPB1C3030S13WE
4		Light sources maker model	FPB1C3030S13WE

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explanation of the step	Pictures	Tools
<b>Step 1</b>	Remove the drive: First press the female buckle to separate the male and female terminals and remove the driver		By hand.
<b>Step 2</b>	Remove the backplane: Use a φ5 Phillips screwdriver to turn the screw on the cable cover counterclockwise to remove the backplane.		φ5 Cross screwdriver
<b>Step 3</b>	Remove the backboard. The backboard is sharp. Be careful not to scratch your hands.		By hand.
<b>Step 4</b>	Pick up the optical kit, including diffusion plate, light guide plate, and reflective paper		By hand.
<b>Step 5</b>	Cut the light source strips. Use a knife to cut the two light source strips. Please be careful not to cut your hands		knife
<b>Step 6</b>	The light source bar is pasted on the front of the back plate as the module for testing photoelectricity		By hand.